

Product parameters

Parameter	
Model No	276710
Solar Panel	Monocrystalline silicon 5V/0.9W*3
Battery	18650 lithium iron phosphate battery 3.2V/1300mAh
LED Source	COB 1*2pcs LED
Charging Time	3-5 Hours
Working Time	10-12 Hours
IP Grade	IP54
Function	Light control
CCT	WW 3000K
Main Material	ABS

Solar Wall Light Product Manual



Notice

1. When the lamp is not working or the working time is short, please place the lamp in a location where the sun is shining directly to charge for 2 days. Don't turn on the lamp during the process. If it still doesn't work or working time is short, please contact the factory.
2. The product has light sensor, please use it where there is no light.
3. Rainy weather will affect the charging of lamp, the working time will be reduced.
4. Don't install the lamp in a place that is easily immersed in water.
5. Don't install the lamp in eaves, tree bottoms and other environments where there is no direct sunlight.
6. The lamp has built-in battery, don't throw away directly.

Please charge in the sun for 4 hours before using for the first time.

Check Remarks before use

1. Place lamp under sunshine for 4-6h after you get goods and turn on, because it only reserve part energy in battery.
2. The less time to charge under sunshine, the less time to work at night, Working time depends on surrounding, geography latitude, seasons etc.
3. There is the difference of working time and brightness extent for different light, please note.
4. Please clean the panel and in case of poor charging effect if it happen to have obstacle in panel in using.

Packing Included


- 1 x Solar Column Lamp
- 1 x Positioning paper jam
- 1 x Instruction manual
- 2 x Wood screw
- 2 x Expansion rubber plug

Product Manual



ON/OFF

Press switch at the back of lampbody, then enter working mode.



Reverse the blade to adjust the luminous angle

Light control



It turns on at light automatically.



Cycle switching



During the day, it is charged by the sun.

Installment step



1. Use positioning paper to mark the position where holes need to be punched.



2. Punch the mark with a drill bit



3. Insert the rubber plug into the hole, then screw the wood screw into the rubber plug



4. Turn on the light, then align the hole on the back of the lamp body with the screw sleeve and clamp it, Installation completed